



Drill Template for NHP-SLA-01 Mounting Holes

Place the template in the desired mounting location and mark the holes. Follow all applicable safety precautions when drilling. If you will be using the supplied #6-32 machine screws, drill 4 holes at the marked locations. Then tap the holes for #6-32 threads. If using your own self tapping screws, drill an appropriately sized pilot hole.

Printing Instructions

Print onto 8-1/2" x 11" paper. Select "Actual Size" or "100% Scale" when printing.