



Drill Template for NSP060 Fan Shrouds

Place the template in the desired mounting location and mark the holes. Follow all applicable safety precautions when drilling. Drill a pilot hole for the center hole, then cut using a 2-1/4 inch hole saw. The 4 outer holes should be drilled using a 3/16 inch drill bit.