

NRR-E1



Installation Guide

NRR-E1 Installation Guide

Step 1 – The NRR-E1 can be installed into panels up to 6mm (0.23 in.) thick. To install the weatherproof IR receiver, following all applicable safety precautions drill a 26mm (1.02") diameter hole. Install the IR receiver housing into the hole and secure with clear cover, hand tightening only. Be sure to ensure the cover gasket is properly seated.

Step 2 - Plug the USB into your TV, set top box or other device for power (you may also use a USB wall adapter – not included), then paste the IR transmitter using its own adhesive over the IR receiver on the device you wish to control.

