
## Page-4



Step 4:

Secure the enclosure to pole mounting bracket using the (2) screws supplied with the kit.



Additional adjustable stainless steel mounting bands can be purchased from Altelix.

Four sizes are available for use with pole sizes ranging from 4" diameter to 17.5" diameter.

## **Got Questions?** We are here to help. Contact us at:



sales@altelix.com



USA & Canada Customers: 866-660-9434 International Customers: +1 561-660-9434



**WARNING: INSTALLATION OF THIS PRODUCT NEAR POWERLINES IS** DANGEROUS. FOR YOUR SAFETY, FOLLOW THE INSTALLATION DIRECTIONS



Under some conditions, this enclosure may not prevent electrocution. Users should keep enclosure away from any overhead wires. If enclosure contacts a power line, any initial protection could fail at any time. IF ENCLOSURE NEARS ANY OVERHEAD WIRES, IMMEDIATELY LET GO, STAY AWAY, AND CALL UTILITY COMPANY

#### THIS ENCLOSURE IS DESIGNED TO BE INSTALLED ONLY BY A TRAINED PROFESSIONAL INSTALLER

Warning: To avoid electric shock, grounding must be installed by the installer as part of the installation. The unit must be grounded and installed in accordance with National Electrical Codes (NEC) and any local codes. Note that non-metallic enclosures do not provide grounding between conduit connections.

Warning: Enclosure must be secured using a pad-lock when energized to prevent unauthorized access and shock hazard.

**Important:** Look over the site before beginning installation, and anticipate possible hazards. Select a safe site to install the enclosure.

If you have power lines in the area, call your local electric utility for assistance.

**NEVER** work alone; always have someone near who can summon help.

Check weather conditions. Be sure that the area is not slippery and make sure that rain or thunderstorms are not predicted for the day you install the enclosure.

If you need to use a ladder, make sure it is made of non-conductive (non-metallic) material.

Enclosures improperly installed or installed to an inadequate structure are susceptible to wind damage that can be very serious or even life threatening. Ensure that the installation is properly grounded. Ensure that the enclosure is properly secured and structurally sound to support all loads (weight, wind & ice).

#### **Rooftop Installation Warning**

**DO NOT** assume that just because you're on a roof, you're isolated from ground. You may still be electrocuted or fall off the roof.

Altelix LLC USA: 866-660-WIFI (9434) International: +1 561-660-9434 sales@altelix.com www.altelix.com Copyright (C) 2019 Altelix LLC. All rights reserved. Altelix and the Altelix logo are Trademarks and/or Registered Trademarks of Altelix LLC.

Specifications are subject to change without notice. See www.altelix.com for most current information

IS0061 Rev C 11/06/19

# Page-2



The pole mount bracket kit includes (2) adjustable bands for mounting to poles 1" to 8" in diameter.




Step 1: Feed the (2) bands through the slots in the pole mount bracket.

The mounting bracket features multiple locations to thread the bands so that small to large poles can be accommodated.



## Page-3



Secure the pole mount bracket to pole using the (2) adjustable bands.

For smaller diameter poles the bands can be trimmed as required.



### Step 3:

The enclosure attaches to the pole mounting bracket via a slot on the top of the enclosure. Align this slot with the tab on the top of the pole mount bracket and slide enclosure down onto this tab.