

Assembly Guide

NHBS-RACK-6U

WARNING: READ ALL INSTRUCTIONS BEFORE USE.

Step 4:

Adjust the side panels to the depth required for equipment being installed into the rack. Panel depth: 9.5" min. / 15.5" max.



9.5" to 15.5"

Step 5:

Install the rack in the required location. Wood screws and concrete anchors are provided in the hardware kit. #10-32 screws are provided for securing equipment mounted in rack.

Got Questions?
We are here to help.
Contact us at:



sales@altelix.com



USA & Canada: 866-660-9434
International: +1 561-660-9434



Equipment shown for reference, not included.

Assembling the Equipment Rack

The NHBS-RACK-6U requires assembly before being installed. The following components are included:

- (1) Equipment Rack Back Panel with Hinged Side Panels
- (2) Adjustable Side Panels
- (12) #M5 Assembly Screws and Nuts
- (12) #10-32 Equipment Mounting Screws
- (4) Wood Screws
- (2) Concrete Anchors .

Step 1:
Unfold side panels into place as shown.



Step 2:
Using supplied M5 hardware, secure the side panels in place.



Step 3:
Using supplied M5 hardware, attach the (2) adjustable panels as shown.

